

Modell/Malli/Model	Kod/Koodi/Code							
FLINT	0051 2551 2791							
FNR	2581							
FORMENTI	0051 0821 2551 2571 2791							
FORGESTONE	2801							
FORTRESS	2391 2571							
FRABA	2551 2791							
FRIAC	2551 2581 2791							
FRONTECH	0301 2401 2771							
FUBA	1641							
FUJITSU	0751 1901 2391 2551 2581 2791							
FUJITSU GENERAL	0751 0981 1901							
FUNAI	0301 2391							
FUTURE	2551 2791							
GALAXI	2551 2581 2791							
GALAXIS	1181 1571 2551 2581 2791							
GALAXY	1181 1571							
GALERIA	0301							
GBC	0301 0701 0721 2161 2631							
GE	2591 2601 2611 2621 2701							
GEANT CASIONO	0771							
GEC	0661 2551 2561 2771 2791							
GELOSO	0301 2201 2631							
GEMSOUND	0301							
GENERAL	0301 2591 2601 2661							
GENERAL ELECTRIC	2601 2621							
GENERAL TECHNIC	0301							
GENEXXA	0051 2551 2791							
GITEM	0051							
GM	0301							
GMG	0301 1571							
GOLDHAND	0301							
GOLDSTAR	0051 0301 0621 1131 1241 1631 2391							
	2481 2551 2591 2791							
GOODMANS	0051 0301 1681 1951 2321 2541 2551							
	2611 2621 2631 2701 2791							
GPM	0301							
GRADIENTE	2551 2791							
GRADIN	0051 0301							
GRAETZ	0661 0731 0861 1051 2551 2791							
GRANADA	0051 0361 0641 0931 0951 1511 1951							
	2411 2541 2551 2611 2621 2701 2741							
	2791							
GRANDIN	0771 2011 2551 2631 2791							
GRENADIER	0301							
GRONIC	2581							
GRUNDIG	0331 1211 1221 1231 1241 1251 1261							
	1271 1281 1301 1311 1321 1331 1341							
	1351 2541 2551 2751 2781 2791							
GTT	0301 1571							
HALLMARK	2391							
HANSEATIC	0051 0301 1161 2551 2571 2771 2791							
HANTAREX	0051 0301 2161 2551 2581 2791							
HANTOR	2551 2791							
HARLEY DAVIDSON	2391 2561							
HARRAD	2391							
HARVARD	2391							
HARWOOD	2551 2791							
HAUPPAUGE	2551 2791							
HCM	0301 2791							
HEATHKIT	0051							
HEDZON	2551 2791							
HEMMERMANN	2771							
HIFIVOX	1991 2341 2591 2641 2681							
HIGHLINE	2551 2791							
HILINE	0301							
HINARI	0051 0301 0861 2321 2541 2551 2791							
HIT	2571							
HITACHI	0051 0631 0661 0671 0781 0791 0921							
	0991 1051 1501 1791 1991 2391 2521							
	2541 2551 2561 2591 2621 2771 2791							

HMC	2551							
HMV	2571							
HORIZONT	0051							
HORNYPHON	0051							
HORNYPHONE	2551 2741 2791							
HUANYU	2631							
HUSPI ELEKTRONIK	1571							
HYPHER	0301 2481							
HYPSON	0051 0301 2551 2761 2791							
HYUNDAI	2551 2791							
IBERIA	2551 2791							
ICE	0051 0301 2551 2791							
ICOS	2741							
ICT	2551 2791							
IMA	2391							
IMPERIAL	0051 0611 0691 0871 1111 1181 1571							
	2201 2551 2771 2791							
INDIANA	0051 2551 2791							
INFINITY	0051							
INGELEN	1621							
INGERSOLL	0301							
INNO HIT	0051 0301 1131 2151 2551 2581 2791							
INNOHIT	0051 0301 1131							
INNOVATION	2551 2791							
INTERACTIVE	2551 2571 2591 2681 2741 2791							
INTERBUY	0301 2551 2791							
INTERDISCOUNT	0051							
INTERFUNK	0051 0661 0741 0861 0901 1181 1571							
	2231 2241 2441 2451 2471 2551 2571							
	2591 2681 2741 2771 2791							
INTERNAL	2551 2631 2791							
INTERVISION	0801 2551 2581 2791							
IRRADIO	0051 0301 1081 1131 2481 2551 2791							
IST	0051							
ISUKAI	0051 2551 2791							
ITL	0301							
ITS	0301 2551 2791							
ITT	0721 0911 2771 2801							
ITT NOKIA	2771							
ITV	2551 2631 2791							
JBL	0051							
JEAN	2541							
JETPOINT	0051							
JINLIPU	0301							
JMB	2551 2631 2791							
JOCEL	0081 0091 0211 0221 0231 0341							
JULIBEE	2791							
JUMBOTRONIC	0051							
JVC	0051 0491 0501 0511 0521 0531 0541							
	0551 2541 2801							
KAISER	0051							
KAISUI	0051 0301 2551 2791							
KAPSCH	0661 1901							
KARCHER	0051 0301 2551 2581 2791							
KATHREIN	2551 2791							
KENDO	0051 0301 0711 0981 1901 2551 2581							
	2791							
KENNEDY	0981 1901							
KENWOOD	2391							
KIOTA	0301							
KITON	2551 2791							
KLH	2391							
KNEISSEL	1161 2551 2631 2761 2791							
KOBIC	0301							
KOISTER	2551 2791							
KOLSTER	0051 2581 2771							
KONICHI	0301							
KONKA	2551 2791							

TV-Koder (TV-apparat)/TV-koodit (Televisio)/TV Brands									
Modell/Malli/Model	Kod/Koodi/Code								
KÖNIG	1981								
KORPEL	0051 2551 2791								
KORTING	2211 2241 2571								
KÖRTING	2211 2241								
KOSMOS	2551 2791								
KRAKING	2761								
KRIESLER	2741								
KTV	2391								
KUASHO	0051 2391								
KUBA	2771								
KUBA ELECTRONIC	2771								
LEADER	0301								
LECSON	2551 2791								
LEGEND	0301								
LENCO	0051 0301 0321 2551 2631 2791								
LENOIR	0301								
LEVIS AUSTRIA	2551 2791								
LEYCO	0051 2551 2791								
LG	2551 2591 2791								
LIESENK & TTER	2551 2791								
LIESENKOTTER	0051 2551 2741								
LIESENKÖTTER	0051 2441								
LIFE	0301								
LIFETEC	0301 2551 2631 2791								
LINITRON	2391								
LLOYD	2391								
LLOYD'S	0301								
LOEWE	0051 2251 2551 2571 2791								
LOGIK	2531 2551 2791 2801								
LOGIK	0251 2351								
LUMA	0051 0301 0721 0981 1901 2551 2631								
	2791								
LUMATRON	2551 2791								
LUX MAY	0051 2551 2791								
LUXOR	0631 0671 0741 0781 0791 0811 0901								
	0991 1001 1021 1031 1041 1051 1131								
	1371 1441 1471 1501 1521 2771								
LUXOR SALORA	2001								
LUXOR/SKANTIC	0991								
LXI	0051								
M ELECTRONIC	0301 1501 2591 2601 2621 2771								
M ELECTRONICS	0051 0301 1471 2021								
MACYS	2391								
MADISON	2551 2791								
MAGNADYNE	0051 0301 0701 1571 2151 2191 2201								
	2571 2581								
MAGNAFON	2151 2581								
MAGNASONIC	0051 0301 2391								
MAGNAVOX	0051 2541 2551 2791								
MAGNUM	0171 2551 2791								
MANESTH	0051 2551 2791								
MANHATTAN	2551 2791								
MARANTZ	0051 2551 2791								
MARELLI	2571								
MARK	0051 2551 2631 2791								
MASUDA	2551 2791								
MATSUI	0051 0301 0311 0331 0611 1241 1731								
	2531 2541 2551 2611 2751 2771 2791								
MAVA	2391								
MAXAM	0301								
MAXELL	0301								
MCE	0301								
MCMICHAEL	2561								
MEDIATOR	0051 2471 2551 2741 2791								
MEDION	0201 2551 2791								
MELECTRONIC	1411 1541 2551 2631 2751 2791								
MEMOREX	0301								
MEMPHIS	0301								
MERCURY	0301 2551 2791								

METZ	1191	1201	1241	1281	1301	1331	2231
	2261	2551	2571	2751	2781	2791	
MGA	2551	2791					
MICROMAXX	2551	2791					
MIDLAND	2391						
MINATO	2551	2791					
MINERVA	1241	1301	2751				
	2781						
MINOKA	0051	2551	2791				
MISTRAL ELECTRONIC	2801						
mitsubishi	0051	0301	2301	2311	2411	2421	2511
	2541	2551	2571	2791	2801		
MIVAR	1091	1121	1131	1151	1161	1611	2161
	2181						
MORGAN'S	2551	2791					
MOTOROLA	0051						
MTC	2391	2771					
MULTIBROADCAST	2801						
MULTISTANDARD	2581						
MULTITEC	2551	2791					
MULTITECH	0051	0301	1111	2391	2551	2581	2771
	2791						
MUSIKLAND	2551	2791					
MYRYAD	2551	2791					
NAIKO	2551	2791					
NAKIMURA	2551	2631	2791				
NAMSUNC	0301						
NAONIS	0721						
NATIONAL	0051	0351					
NEC	0301	2531	2541				
	2551	2631	2791				
NECKERMANN	0051	0301	0431	0441	0501	0791	0921
	0981	1181	1241	1261	1281	1301	1331
	2151	2441	2451	2551	2571	2691	2721
	2751	2771	2781	2791			
NEI	0051	1721	2551				
	2791						
NETSAT	2551	2791					
NEUFUNK	2551	2791					
NEUTECH	0051	0301	2551	2621	2791		
NIKKAI	0051	2391	2541	2551	2791		
NIKKO	1711						
NOBLEX	0261	0301					
NOBLIKO	1081	1111	2581				
NOGAMATIC	1991	2341	2591	2641	2681		
NOKIA	0241	0301	0631	0661	0671	0721	0731
	0741	0811	0831	0861	0901	0931	0991
	1001	1041	1051	1391	1401	1421	1431
	1481	1501	1511	1521	1541	1571	1821
	2591	2631	2771				
NOKIA AKAI	0851						
NONAME	0051						
NORDMENDE	1791	1811	1851	1861	1871	1921	1961
	1991	2021	2051	2341	2551	2591	2601
	2611	2621	2641	2661	2681	2701	2791
	2551	2791					
NORMEREL	0051						
NOVABEAM	2741						
NOVAK	0051	0301	2551	2631	2791		
NOVATRONIC	0301						
O GENERAL	0771	0811	0991	1051	1501	1521	2011
OCEANIC	0301	2551	2791				
OKANO	0301						
OLYMPIC	0301						
ONCEAS	0301						
ONWA	2581						
OPERA	0051	2551	2791				
ORBIT	0051	2551	2791				
ORIENT	0301						

TV-Koder (TV-apparat)/TV-koodit (Televisio)/TV Brands	
Modell/Malli/Model	Kod/Koodi/Code
ORION	0051 0121 0131 0141 0151 0301 0961
	0971 2111 2391 2531 2551 2581 2791
ORLINE	2551 2791
ORMOND	2551 2791
OSAKI	2551 2631 2791
OSIO	2551 2791
OSUME	2541 2551 2791
OTF	0301
OTTO VERSAND	0051 0301 0411 0421 0431 0441 0451
	0621 0791 0801 1261 1271 1281 1331
	2021 2371 2481 2491 2541 2551 2591
	2621 2721 2751 2771 2781 2791
OTTO-VERSAND	0051 0301 0441 0471 0561 0801 1241
	1261 1301 1631 2021 2111 2371
PACIFIC	0091 0101 2551 2791
PAEL	1081
PALLADIUM	0051 1281 2551 2571 2691 2721 2751
	2771 2781 2791
PALSONIC	2551 2791
PANAMA	0301 2551 2791
PANASHIBA	0301
PANASONIC	0051 0351 0361 0371 0381 0391 1191
	2361 2371 2551 2791
PANAVISION	2551 2791
PANAVOX	0301
PANORAMA	0301
PATHE CINEMA	1161 2761 2771
PATHE MARCONI	1991 2341 2591 2641 2681
PAUSA	0301
PCE/PEC	2391
PENNEY	2391
PERDIO	2551 2791
PERFEKT	0051 2551 2791
PHILCO	0051 0301 0691 0701 1111 1181 1571
	2201 2551 2571 2791
	2801
PHILEX	2551 2561 2571 2621 2631 2651 2741
PHILIPS	2751 2761 2781 2791 2801 2811
	0051 2471
PHILIPS (F)	0051 2551 2571 2791
PHOENIX	0051 2471 2551 2571 2741 2791 2801
PHONOLA	2551 2791
PILOT	0051 0761 1791 2551 2591 2601 2621
PIONEER	2651 2791
	0051 0301 2551 2791
PLANTRON	2571 2581 2591 2681 2761
POLICOM	0301
POPPY	0301
PORTLAND	2391 2631
PRANDONI PRINCE	0721 1081
PRANDONI-PRINCE	2151
PRIMA	0051 0301 2391
PRINCESS	0301
PRINZ	2771
PROELCO	0051
PROFEX	0301 0801 1111
PROFITRONIC	0051 2551 2581 2791
PROLINE	2551 2711 2741 2791
PROSONIC	2551 2631 2791
PROTEC	0051 0301
PROTECH	2551 2581 2771
PROTECT	2791
PROTON	0301 2391
PROVISION	2551 2791
PULSER	0051 0301 2391
PYE	0051 2551 2571 2631 2741 2771 2781
	2791
PYMI	0301

QUELLE	0051	0301	0411	0421	0431	0441	0451
	0471	0501	0621	0871	0981	0991	1081
	1101	1131	1241	1271	1281	1301	1331
	1371	1381	1451	1471	1521	1661	1671
	1901	2311	2371	2391	2441	2451	2461
	2481	2531	2541	2551	2591	2681	2691
	2721	2751	2771	2781	2791		
QUESTA	2541						
R LINE	0051	2551	2791				
RADIALVA	2551	2591	2601	2791			
RADIO SHACK	2391	2551	2791				
RADIOLA	0051	2471	2551	2741	2791		
RADIOMARELLI	2151	2551	2571	2791			
RADIOSTONE	2791						
RADIOTONE	0051	0301	2551				
RANK ARENA	2541						
RANK/BUSH/MURPHY	1141						
RCA	2611	2621	2701	2711			
RECOR	2551	2791					
RECORD	0051						
RECTILIGNE	2551	2791					
REDIFFUSION	2541						
REDSTAR	2551	2791					
REFLEX	2551	2791					
REGENTE	0301						
REVOX	0051	2551	2791				
REVOX/STUDER	0051						
REX	0711	0751	0981	1161	1901	2201	
RFT	1161	1171	2551	2571	2791		
RICOH	2551	2791					
RMB	2391						
ROADSTAR	0301	2551	2791				
ROBOTRON	2571						
RODEX	2551	2791					
ROSITA	0301						
ROWA	0301						
ROYAL	0301						
ROYAL LUX	2611						
RUKOPIR	2551	2791					
SABA	0661	0861	1061	1791	1801	1811	1851
	1991	2021	2031	2041	2151	2331	2341
	2571	2591	2601	2611	2621	2641	2661
	2681	2701	2711				
SACCS	2761						
SAISHO	0051	2531					
SAIVOD	2551	2791					
SAKURA	0301						
SALORA	0631	0641	0741	0791	0811	0921	0991
	1001	1041	1051	1131	1391	1471	1491
	1501	1521	1541	1821	2771		
	2611						
SALSA	1081	1111	1131	2151	2581		
SAMBERS	2391						
SAMPO	0051	0161	0181	0261	0301	1131	1661
SAMSUNG	2391	2401	2551	2791			
	2391						
SAMSUX	2761						
SANELA	2391						
SANKY	0051	0301	2391				
SANSUI	2551	2791					
SANYO	0301	1161	1671	2311	2531	2541	2551
	2791						
SAVE	2551	2791					
SBR	0051	2471	2551	2561	2741	2791	2801
SCHAUB LORENZ	0991	1051	2631	2771			
SCHNEIDER	0051	0161	0171	0301	0861	0941	0981
	1161	2471	2481	2491	2551	2621	2741
	2771	2791					
SCHNEIDER (F)	2471						
SCOTT	2391						

DAEWOO	0322							
DECCA	0002	0132	0642					
DECCA (UK)	0002							
DEGRAAF	0002	0132	0232	0302				
DIXI	0142							
DUAL	0332							
DUMONT	0002	0132	0232					
DYNATECH	0132							
EMERSON	0132	0212	0222					
FERGUSON	0412	0422	0552	0602	0712	0722	0782	
FIDELITY	0132							
FINLANDIA	0002	0232						
FINLUX	0002	0082	0132	0162	0192	0232	0272	
	0302	0612						
FIRST LINE	0612							
FISHER	0182	0232	0242	0272	0292			
FORMENTI-PHOENIX	0002							
FUNAI	0132							
GEC (UK)	0002							
GENERAL TECHNIC	0872							
GOLDSTAR	0512	0652						
GOODMANS	0132	0202						
GRANADA	0002	0232	0272					
GRANADA (UK)	0002	0012	0162	0302	0512	0522		
GRUNDIG	0002	0012	0452	0502	0942	0952	0962	
	0972	0982	0992	1002				
HANSEATIC	0002	0512						
HARMAN/KARDON	0622							
HINARI	0112	0142	0222					
HITACHI	0132	0302	0362	0512	0722			
IMPERIAL	0132							
INGERSOL	0142							
INNO HIT	0002							
INNOVATION	0842	0862	0872					
INTERFUNK	0002							
ITT	0192	0232	0272	0462				
ITT-NOKIA	0192	0232	0272	0462				
JVC	0442	0462	0482	0602				
KARCHER	0002	0512						
KENDO	0192							
KENWOOD	0272							
LIFETEC	0842	0862	0872					
LLOYD	0132							
LOEWE OPTA	0002	0012	0022					
LOGIK	0142							
LUXOR	0192	0272	0512					
M ELECTRONIC	0132							
MAGNADYNE	0002							
MAGNASONIC	0272							
MARANTZ	0002	0012	0202					
MATSUI	0002	0142	0212	0222	0512	0672	0902	
	0912	0922	0932					
MEDION	0842	0862	0872					
MEMOREX	0132	0182	0232	0272				
METZ	0012	0632						
MGA	0612							
MICROMAXX	0842	0862	0872					
MINERVA	0012							
MINOLTA	0302							
MINOLTA	0002	0612	0622	0672				
MITSUBISHI	0132							
MTC	0002	0132						
MULTITECH	0002							
MURPHY	0132							
N.E.I.	0002							
NATIONAL	0162							
NECKERMANN	0002	0012	0222	0272	0462	0512		
NOBLIKO	0012							
NOKIA	0192	0232	0272	0462	0852			

VCR-Koder (Videobandspelare)/VCR-Koodit (Videonauhuri)/ VCR Brands

Modell/Malli/Model	Kod/Koodi/Code							
NORDMENDE	0092	0102	0332	0432	0442	0462	0482	
	0492	0532	0542	0572				
OLYMPUS	0162							
OPTIONICA	0202							
ORION	0142	0212	0222	0682				
OSAKA	0132							
OSAKI	0132							
OTTO VERSAND	0002	0512						
PAENTAX	0302							
PANASONIC	0162	0372	0692	0792	0802	0882		
PERDIO	0132							
PHILCO	0762							
PHILIPS	0002	0012	0022	0062	0072	0082	0172	
	0202	0772						
PHONOLA	0002	0022						
PIONEER	0002	0072	0172					
PROLINE	0132							
PYE	0002	0022						
QUARTZ	0272							
QUELLE	0002	0012	0162	0222	0642			
REALISTIC	0132	0182	0202	0232	0272			
RET	0772							
REX	0442	0482						
RICOH	0652							
SABA	0092	0332	0432	0442	0462	0472	0482	
	0492	0572						
SAISHO	0142	0212	0222	0672				
SALORA	0272	0512	0522	0612				
SAMSUNG	0002	0322	0352	0892				
SANYO	0182	0232	0262	0272				
SBR	0002	0022						
SCHNEIDER	0002	0132						
SEI-SINUDYNE	0142							
SHARP	0202	0402						
SIEMENS	0012	0272						
SINUDYNE	0002	0082	0142	0632				
SONITRON	0232	0272						
SONY	0132	0252	0382	0392	0642	0652	0662	
	0822	0832						
STS	0302							
SUNKAI	0212							
SUNSTAR	0132							
SYLVANIA	0132	0612						
SYMPHONIC	0132	0612						
TANDBERG	0222	0632						
TASHIKO	0132							
TATUNG	0002	0132	0622					
TCM	0842	0862	0872					
TEAC	0132							
TECHNICS	0162							
TEKNIKA	0132							
TELEFUNKEN	0332	0432	0442	0462	0482	0582	0592	
TEMPEST	0732	0742	0752					
THOMSON	0102	0332	0462					
THORN	0602							
THORN-FERGUSON	0412	0422	0442	0462	0552	0562	0572	
	0602							
TMK	0222							
TOSHIBA	0322	0612						
TRIUMPH	0622							
VIDEON	0862	0872						

SAT -Koder (Satellitmottagare)/ SAT -Koodit (Satelliitivastaanotin)/SAT Brands

Modell/Malli/Model	Kod/Koodi/Code							
AKAI	0263							
ALBA	0263							
AMSTRAD	0283	0573	0583	1573				
ASTRO	0663							
AUSTAR	0463	0723						
AVANDIS	1003							
BRITISH TELECOM	0263							
BSKYB	1573							
BT	0293	0633						
CAMBRIDGE	0023	0263						
CANAL+	0353	1633	1643					
CGV FREEVIEW	1653	1663	1683					
D-BOX	0153	0903						
ECHOSTAR	0093							
ELTA	0273							
EURODEC	0213	0223	0233					
FERGUSON	0013							
FORCE	1093	1123						
FOXTEL	0453	0483	0743	0813	1533			
GRADIENTE	1593							
GRUNDIG	0673	0683	0693	1573				
HIRSCHMANN	0393	0403	0413	0423	0433			
HUMAX	1053							
JVC	0263							
KATHREIN	0383							
KYOSTAR	0073							
LIFESAT	0313	0333	0343					
MACAB	0933							
MEDION	0313	0333						
METRONIC	0963	0973	0983	0993	1013	1023	1033	
MICROMAXX	0313	0333						
MULTICHOICE	0733							
NIKKO	0123	0133						
NOKIA	0143	0803	0883	0893	0913	0943	1133	
	1153	1163	1523					
ONDIGITAL	0513	0853	0863	1373	1383	1523	1553	
	1563							
OURALIS	1043							
PACE	0513	0563	0613	0623	0783	0793	0803	
	0873	1373	1573	1593				
PANASONIC	0453	1573						
PANSAT	0063							
PHILIPS	0113	0173	0183	0193	0523	0753	0763	
	0773	0803	0843	0853	0863	1553	1563	
PROSAT	0163							
SAGEM	0243	0923	1113	1393	1603			
SAMSUNG	0553	1103						
SATELLITE	0533							
SECTOR	0253							
SEDEA	0083							
SKY (SKY Digital)	0443	1573	1583	1593				
SKY ITALY	1673							
SKY MASTER	1343	1353	1433	1443	1473	1483		
SKY SATELLITE	1363	1423	1503	1513				
SKY+ (SKY Digital +)	1543							
SONY	1573							
STRONG	0073	1173	1183	1193	1203	1213	1223	
	1233	1243	1253	1263	1273	1283	1293	
	1303	1313	1323	1333				
SUN/MOON/STAR	0463							
TANDBERG	0103							
TELE+	0833							
TELEVES	0003	0033	0043	0053	0303	0473	0493	
	0503	0543	0643	0653	0703	0713	0823	
	1063	1073	1403	1413	1453	1463	1493	
THOMSON	1143	1603						
THORN-FERGUSON	0013							
TOSHIBA	1383							
TPS	0363	1413	1603	1613	1623			

**SAT -Koder (Satellitmottagare)/
SAT -Koodit (Sateliittivastaanotin)/SAT Brands**

Modell/Malli/Model Kod/Koodi/Code

TRIAD	1143			
VORTEC	0063			
WORLDSAT	0593	0603		
XSAT	0373	0953		
ZEHNDER	0203	0323		
ZENITH	1583			
ZINWEL	1083			

CTV -Koder (Kabeltelemottagare)/

CTV-Koodit (Kaapeliteleviiovastaanotin)/CTV Brands

Modell/Malli/Model Kod/Koodi/Code

AUSTAR	0194			
CABLETIME	0084	0094	0114	
CLYDE CABLEVISION	0064			
FILMNET	0034	0074		
FOXTEL	0154	0164	0174	
FRANCE TELECOM	0024			
GEC	0064			
G.I.	0194	0214		
HK CABLE	0204	0254		
JERROLD	0054			
MOVIE TIME	0104			
NOW BROADBAND TV	0244			
NSC	0104			
OPTUSVISION	0184			
PHILIPS	0024			
SAMSUNG	0134			
SCIENTIFIC ATLANTA	0124	0144		
SKYMASTER	0224	0234		
STARCOM	0054			
STS	0104			
TELE	0074			
TELE+1	0074			
TELESERVICE	0044	0114		
TUDI	0014			
UNITED CABLE	0054			
ZENITH	0044			

**DVD -Koder (DVD-spelare)/DVD-Koodit (DVD-soitin)/
DVD Brands**

Modell/Malli/Model Kod/Koodi/Code

3DLAB	0155			
ACOUSTIC SOLUTIONS	0545			
AEG	0505			
AIWA	0545	0565		
AKAI	0035	0435	0505	
ALBA	0515	0525	0585	
AMSTRAD	0585			
ANSONIC	0355			
APEX DIGITAL	0405			
AWA	0375			
A-TREND	0555			
BLACK DIAMOND	0585			
BLUE SKY	0405	0455	0525	0585
BOMAN	0395			
BRANDT	0685			
BUSH	0355	0425	0515	0525 0585 0635
CAMBRIDGE AUDIO	0495			
CENTRUM	0585			
cineULTRA	0525			
CGV	0325	0415	0695	0705 0715
CLASSIC	0545			
CLATRONIC	0505			

CONIA	0405			
CROWN	0345	0685		
CYBERCOM	0355			
CYBER HOME	0265	0555		
CYTRON	0365	0685		
DAEWOO	0345	0365		
DANSAI	0345	0395		
DECCA	0345			
DENON	0025			
DENVER	0505	0525		
DENZEL	0385			
DIAMOND	0535	0685		
digiRED	0515			
Digitrex	0405			
DiK	0355			
DiViDo	0365			
DMTECH	0395			
DUAL	0385	0395	0545	0585 0685
ELTA	0425			
EMERSON	0365			
ENZER	0385			
FERGUSON	0685			
FINLUX	0345	0395	0575	
GE	0515			
GLOBAL SPHERE	0535			
GOLDSTAR	0125	0575		
GOODMANS	0395	0425	0435	0685
GO VIDEO	0395			
GRAETZ	0385			
GRUNDIG	0155	0365	0435	0455 0585 0685
GRUNKEL	0345			
HANSEATIC	0575			
HARMAN/KARDON	0205			
HDT	0365			
HITACHI	0095	0195	0225	0275 0385
HITEKER	0405			
HYUNDAI	0395			
ISP	0455			
JAMO	0595	0605		
JMB	0455			
JOCEL	0615			
JVC	0015	0135	0145	0155 0485
KARCHER	0395			
KENDO	0525			
KENWOOD	0025	0085		
KISS	0385			
LASONIC	0115			
LAWSON	0365			
LECSON	0625			
LENCO	0345	0355	0525	0685
LENOXX	0425			
LEXIA	0525			
LG	0125	0575		
LIFETEC	0355	0685		
LIMIT	0535			
LINN	0245			
LOEWE	0155	0255		
LOGIC LAB	0535			
LOGIX	0365	0395		
LUMATRON	0365			
LUXMAN	0095			
MAGNAVOX	0055	0015	0445	0485
MANHATTAN	0365			
MARANTZ	0155			
MATSUI	0455	0685		
MBO	0425			
MEDION	0355	0395	0685	
METZ	0185	0585	0665	

**DVD -Koder (DVD-spelare)/DVD-Koodit (DVD-soitin)/
DVD Brands**

Modell/Malli/Model Kod/Koodi/Code

MICROMEDIA	0015	0155	0485	
MICROMEGA	0155			
MICROSOFT	0655			
MICROSTAR	0355			
MINAX	0585			
MITSUBISHI	0005	0585		
MONYKA	0385			
MUSTEK	0545			
Mx ONDA	0685			
NAD	0215	0575		
NAIKO	0345			
NEUFUNK	0385			
NORDMENDE	0355			
ONKYO	0015	0055	0105	0485
OPTIMUS	0175	0185	0665	
ORION	0455			
ORITRON	0685			
PACIFIC	0305	0335	0355	0435 0535
PALLADIUM	0455			
PALSONIC	0405	0635		
PANASONIC	0025			
PHILIPS	0015	0055	0155	0255 0485
PHONOTREND	0525			
PIONEER	0175	0185	0665	
PROLINE	0615	0685		
PROSCAN	0655			
PROSONIC	0525			
PROVISION	0525			
RADIONETTE	0575			
RAITE	0385			
RCA	0655			
REC	0025	0635		
RED STAR	0345	0505		
REOC	0535			
REVOY	0525			
ROADSTAR	0425	0525	0635	
ROTEL	0145			
SABA	0685			
SALORA	0575			
SANSUI	0455	0505		
SAMSUNG	0095	0225		
SCAN	0365			
SCHAUB LORENZ	0505			
SCHNEIDER	0365	0395	0435	0685
SCIENTIFIC LABS	0535			
SCOTT	0405	0685		
SEG	0385	0535	0585	
SHARP	0645			
SHANGHAI	0405			
SHERWOOD	0575			
SHINCO	0515			
SHINSONIC	0075			
SILVA	0505			
SILVASCHNEIDER	0355			
SINGER	0425			
SKYMASTER	0545			
SLIM ART	0345			
SM ELECTRONICS	0425	0535	0545	
SONY	0045	0095	0235	0285 0675
SONY-PS2	0165			
SOUNDMASTER	0535			
SOUNDWAVE	0395			
STANDARD	0535	0685		
SUNWOOD	0505			
SVA	0405			
TATUNG	0345			
TEAC	0185	0435	0515	0535 0575
TECHNICS	0025			

TECHNIKA	0345				
TECHWOOD	0585				
TENSAI	0425	0685			
TEVION	0685				
THETA DIGITAL	0185				
THOMSON	0015	0135	0655		
TOKAI	0385	0505			
TOKIWA	0365				
TOSHIBA	0015	0055	0465	0475	0485
UNITED	0505				
UNIVERSUM	0125	0575	0585		
VENTURER	0435				
VIETA	0365				
VOXSON	0355	0545			
WALKVISION	0515				
WESDER	0525				
WHARFEDALE	0615	0625			
XMS	0505	0635			
X-BOX	0295				
YAMAHA	0025	0065	0155		
YAMAKAWA	0385				
YUKAI	0545				
ZENITH	0015	0055	0125	0485	0575