




1






2 2.4 G / OFF / BT




3




4




5




6 2.4 Ghz



7 Sleep Mode (Standby)



8 Buttons



9 Software

Download the installation file by going to "https://www.clasohlson.com/" and search for the product. Double-click the installation file and follow the instructions.

Ladda ned installationsfilen genom att gå till "https://www.clasohlson.com/" och sök efter produkten. Dubbelklicka på installationsfilen och följ anvisningarna.

Last ned installasjonsfilen ved å gå til «https://www.clasohlson.com/ og søk etter produktet. Dobbeltklikk på installasjonsfilen og følg anvisningene.

Lataa asennustiedosto menemällä osoitteeseen "https://www.clasohlson.com/" ja etsi tuote. Kaksoisnapsauta asennustiedostoa ja noudata ohjeita.

Download installationsfilen ved at gå til "https://www.clasohlson.com/" og søg efter produktet. Dobbeltklik på installationsfilen, og følg anvisningerne.

Simplified EU Declaration Of Conformity

Hereby, Clas Ohlson AB declares that the radio equipment type **MS1040WB** is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.clasohlson.com

exibel®

Exibel MS1040WB

10-1-394

Complete manual

www.clasohlson.se

www.clasohlson.no

www.clasohlson.fi