



Back-up Battery CR2032



(sold separately)





Clock Mode

First Use



1




Adjust Time Setting

1




2




Clock Mode

Set Alarm (ex. alarm 1)

1




2



3



4




* set volume level in radio mode



Clock Mode

Activate


Deactivate




Snooze

Clock Mode

1



2




Clock Mode

1




2





Clock Mode

Dimmer




11:45

Clock Mode

Display ON/OFF


Turn OFF

Turn ON




Radio Mode

FM Radio




Volume




Auto tuning


Manual tuning



Store a radio station



Select a preset radio station




Zz

Radio Mode

Sleep

Sleep timer, 0-90min



Power consumption in standby mode: 0.53 W

36-7960

AV1106