

Back-up Battery CR2032



(sold separetely)



Clock Mode

Dimmer



Clock Mode

Display ON/OFF

Turn OFF



Turn ON



Clock Mode

First Use



Adjust Time Setting



Clock Mode

Set Alarm (ex. alarm 1)



* set volume level in radio mode

Radio Mode

FM Radio



Volume



Auto tuning



Manual tuning



Store a radio station



Select a preset radio station



Clock Mode



Snooze

Clock Mode



Clock Mode



Radio Mode

Sleep

Sleep timer, 0-90min



36-7960
AV1106

clas ohlson