

# x5 USB Multi-Port Charging Hub

Art.no 38-9369

Model PW07

Please read the entire instruction manual before using the product and then save it for future reference. We reserve the right for any errors in text or images and any necessary changes made to technical data. In the event of technical problems or other queries, please contact our Customer Services.


## Safety

- Do not open the housing. Certain unshielded components inside the housing carry dangerous voltages. Contact with these components could result in an electric shock.
- The product must not be taken apart or modified.
- Never use the product if it has been damaged in any way.
- Do not use the product with devices which require a charging current of more than 2400 mA via USB Type-A and 3000 mA via USB Type-C.
- Make sure that the wall socket is easily accessible in case the product needs to be unplugged quickly from the mains.
- The product is intended for indoor use only.
- Do not place the product where it could fall into water or other liquid.
- Only charge devices with rechargeable batteries, NEVER attempt to recharge any other types of batteries.
- Always switch off any device before connecting it to the product.

## Product description

- Suitable for charging iPhones, iPads, Android telephones and most tablets.
- Protects against overcurrent and short-circuiting.

1. LED indicator, turns on when the charging hub is connected to the mains
2. PD (Power Delivery) USB Type-C port for quick charging 5.0 V/3.0 A, 9.0 V/2.0 A and 12.0 V/1.5 A
3. 4 x USB Type-A 5.0 V/2.4 A (total power load 30.0 W) USB Type-A 30.0 W)



## Charging

1. Connect the device to be charged to one of the USB ports using a cable.
2. Connect the charging hub to a wall socket. The LED indicator will come on.

## Care and maintenance

- Always unplug the mains lead before cleaning and use a soft dry cloth to clean the exterior of the charging hub if required.
- Unplug the charging hub from the wall socket and store it in a dry, dust-free environment out of the reach of children whenever it is not to be used for an extended period.

## Troubleshooting guide

The connected device does not charge.

- Check that the cable connecting the device to the charging hub is intact and properly connected.
- Is the charging hub properly connected to the wall socket?
- Is the wall socket energised?

## Responsible disposal

This symbol indicates that this product should not be disposed of with general household waste. This applies throughout the entire EU. In order to prevent any harm to the environment or health hazards caused by incorrect waste disposal, the product must be handed in for recycling so that the material can be disposed of in a responsible manner. When recycling your product, take it to your local collection facility or contact the place of purchase. They will ensure that the product is disposed of in an environmentally sound manner.



## Specifications

**Input voltage** 100-240 V~, 50/60 Hz

**Output voltage**  
**USB Type-C** 5.0 V 3.0 A 15.0 W  
9.0 V 2.0 A 18.0 W  
12.0 V 1.5 A 18.0 W

**Output voltage**  
**USB Type-A** 5.0 V 2.4 A 12.0 W max 30 W

**Size** 92 x 59 x 27 mm

### Energy related Products (ErP) Directive

<b>Model</b>	38-9369, PW07
<b>Input voltage</b>	AC 100-240V
<b>Input AC frequency</b>	50-60Hz
<b>Output voltage(port C)</b>	DC 5.0V/9.0V/12.0V
<b>Output current(port C)</b>	3.0A/2.0A/1.5A
<b>Output power(port C) Total</b>	15.0W/18.0W
<b>Output voltage(port A) Total</b>	5.0V
<b>Output current(port A) Total</b>	6.0A
<b>Output power(port A) Total</b>	30.0W
<b>Average active efficiency</b>	84.81%/85.23%/85.55%
<b>Efficiency at low load (10%)</b>	82.45%/81.37%/80.33%
<b>No-load power consumption</b>	0.098W/0.097W/0.097W